

Without Piezo Button



SLZA 20

88200

Shower control without piezo button for coin and token shower timers with index M - premixed water



SLZA 20H

88205

Shower control without piezo button for coin and token shower timers with index M - for cold and hot water, temperature regulated by mixer



SLZA 20T

88206

Shower control without piezo button for coin and token shower timers with index M - for cold and hot water, temperature regulated by thermostatic mixer



SLZA 21

88210

Stainless steel shower panel without piezo button for coin and token shower timers with index M - premixed water



SLZA 21H

88215

Stainless steel shower panel without piezo button for coin and token shower timers with index M - for cold and hot water, temperature regulated by mixer



SLZA 21T

88216

Stainless steel shower panel without piezo button for coin and token shower timers with index M - for cold and hot water, temperature regulated by thermostatic mixer

With Piezo Botton



SLZA 20P

88207

Shower control with piezo button for coin and token shower timers with index N - premixed water



SLZA 20PH

88208

Shower control with piezo button for coin and token shower timers with index N - for cold and hot water, temperature regulated by mixer



SLZA 20PT

88209

Shower control with piezo button for coin and token shower timers with index N - for cold and hot water, temperature regulated by thermostatic mixer



SLZA 21P

88217

Stainless steel shower panel with piezo button for coin and token shower timers with index N - premixed water



SLZA 21PH

88218

Stainless steel shower panel with piezo button for coin and token shower timers with index N - for cold and hot water, temperature regulated by mixer



SLZA 21PT

88219

Stainless steel shower panel with piezo button for coin and token shower timers with index N - for cold and hot water, temperature regulated by thermostatic mixer